

HERITAGE SERIES CASEMENTS

INSWING CASEMENTS | SINGLE UNIT

INSWING CASEMENTS | TWO-WIDE FRENCH

U.D.	2'-2 3/4"			
R.O.	2-1"			
G.S.	19 13/16"			
3'-1 3/4"	3'-0 1/2"	29 1/8"		KWIW13
3'-7 3/4"	3'-6 1/2"	35 1/8"		KWIW136
4'-1 3/4"	4'-0 1/2"	41 1/8"		KWIW14
4'-7 3/4"	4'-6 1/2"	47 1/8"		KWIW146
5'-1 3/4"	5'-0 1/2"	53 1/8"		KWIW15
5'-7 3/4"	5'-6 1/2"	59 1/8"		KWIW156
6'-1 3/4"	6'-0 1/2"	65 1/8"		KWIW16

U.D.	3'-6 1/4"	4'-2 1/4"	5'-2 1/4"					
R.O.	3'-4 1/2"	4'-0 1/2"	5'-0 1/2"					
G.S.	15 13/16"	19 13/16"	25 13/16"					
3'-1 3/4"	3'-0 1/2"	29 1/8"		FWIN23*		FWIW23*		FWIX23*
3'-7 3/4"	3'-6 1/2"	35 1/8"		FWIN236*		FWIW236*		FWIX236*
4'-1 3/4"	4'-0 1/2"	41 1/8"		FWIN24*		FWIW24*		FWIX24*
4'-7 3/4"	4'-6 1/2"	47 1/8"		FWIN246*		FWIW246*		FWIX246*
5'-1 3/4"	5'-0 1/2"	53 1/8"		FWIN25*		FWIW25*		FWIX25*
5'-7 3/4"	5'-6 1/2"	59 1/8"		FWIN256*		FWIW256*		FWIX256*
6'-1 3/4"	6'-0 1/2"	65 1/8"		FWIN26*		FWIW26*		FWIX26*

NOTES:

All measurements are nominal. Elevation charts are not to scale.

Grilles are optional. Follow chart down from top row and across from left column to determine grille configurations.

Some installation procedures will require a larger rough opening than noted (i.e. installations utilizing our installation clips), therefore, you may need to increase the rough opening size accordingly. Rough opening gaps may be increased up to a maximum of 1/2" on all sides and still be within good practice guidelines.

* Units meet most national emergency escape and rescue requirements.

PRODUCT CODES:

To order, add use the product number shown. Specify stationary, left or right venting when ordering single units. Venting is viewed from the window exterior.

U.D. = Unit Dimension • R.O. = Rough Opening • G.S. = Glass Size (Glass sizes are shown per sash.)